

Firmware Version Check Utility for MasterConsole® Digital KVM CIMs


Date: May 2019

Applicability:


MDCIM-DVI / MDCIM-HDMI / MDCIM-DP / MDUTP20 / MDUTP40 / MDUTP60 / MDUTP150

Get started:


1. Run “**UVCView.x86.exe**” in the CIM_FW_Check_Utility folder



2. Select the “Auto Refresh”, “Show Config Descriptors” and “Show Description Annotations” in the **Options** menu.




3. Plug in a MDCIM or MCUTP cable to a USB port on your computer.
You will see the new “**USB Composite Device**” that shows on the utility panel (Before / After).




4. In case you don't know which USB Port is connecting to the MDCIM or MCUTP, you can check the **“Device Information”** from the top of the right panel.

- **Firmware Before v2.0 → “HID Device”**



- **Firmware After v2.0 → “Dongle”**



5. Check the firmware version to verify the updated firmware, please check “**iSerialNumber**” field from the right hand panel

